
Putting on the Every Muscle Suit [For use mainly in a standing posture]





Step.1

Put on the Muscle Suit with both shoulder straps on the shoulders like when you put on a backpack.




Step.2

Lift the adjusters of the shoulder straps until the hip belt is at the height of vour hips.




Step.3

Fasten the hip belt and tighten the belt using the right and left adjusters.



Step.4

Adjust the length of the buttock belt.




Step.5

Move the thigh pads to the front.




Step.6

Pump the air pump 30 to 45 times to fill the artificial muscles with air.



Step.7

Adjust the space between your back and the suit using the shoulder straps' adjusters.




Step.8

Fasten the right and left adjusters in front of the chest.

Step.9


Muscle Suit is now ready to assist with crouching and straightening the upper body.

> Starting support




Option Step

Adjust the assistive force by increasing or reducing the air volume.



Putting on the Every Muscle Suit [For use mainly in a crouching posture]






Step.1

Put on the Muscle Suit with both shoulder straps on the shoulders like when you put on a backpack.




Step.2

Lift the adjusters of the shoulder straps until the hip belt is at the height of your hips.



Step.3

Fasten the hip belt and tighten the belt using the right and left adjusters.



Step.5

Move the thigh pads to the front.



Step.6

Pump the air pump 30 to 45 times while in a crouching posture to fill the artificial muscles with air.

Step.7

While in a crouching posture, adjust the space between your back and the suit using the shoulder straps' adjusters.



Fasten the right and left adjusters in front of the chest.



Step.9


Step.4

buttock belt.


Adjust the length of the

Muscle Suit is now ready to assist with crouching and straightening the upper body.

Starting support



Pumping





Point.2

Leave space at your back.



Option Step

Adjust the assistive force by increasing or reducing the air volume.

